



Lenovo ThinkPad W520 Battery Replacement

This guide shows you how to remove your laptop's battery. It also applies to Lenovo ThinkPads T510, W510, T520, T530, and W530.


Written By: Andrew Schneider



INTRODUCTION

This guide will instruct you how to remove your laptop's battery.

Step 1 — Battery



- ✦ Make sure your laptop is unplugged and powered off.
- Use your left hand and push the unlock switch all the way to the right.
- Use your right hand to push the battery.

Step 2



- Slide the battery out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-27 02:33:21 PM.